

## HOW TO MEASURE FOR YOUR FREEZEPRO<sup>®</sup> WRAP

Selecting the right size FreezePro<sup>®</sup> Wrap for your equipment is a lot easier than you might think. All you need is a tape measure, and you are ready to go!


**WARNING:** When installing or measuring for FreezePro<sup>®</sup> Wrap, please follow all safety precautions and use proper and adequate protective safety aids such as: protective gloves and suitable protective clothing. Never use a metal tape for measuring purposes. Failure to do so may result in injury.

### 1. MEASURE FOR EITHER THE (1) CIRCUMFERENCE **OR** (2) DIAMETER:



**CIRCUMFERENCE**

**OR**



**DIAMETER**

**NOTE:** It does not matter which method of measurement you decide to use. Just remember that you only need to find your measurement using one of the two ways described above.

### 2. MEASURE FOR THE DESIRED WIDTH:



**WIDTH**

**NOTE:** After finding either the circumference or diameter, measure for the desired width to determine the width measurement of the application you want to insulate.



### 3. FIND THE RIGHT FREEZEPRO® WRAP:

The **CIRCUMFERENCE** (length) is 20in and the desired width is 12in = **FPW 3012**.  
**FOR EXAMPLE:** OR  
 The **DIAMETER** (length) is 6in and the desired width is 12in = **FPW 3012**.

## WIDTH

CIRCUMFERENCE	DIAMETER	6in (152mm)	12in (305mm)	18in (457mm)	24in (610mm)
0in - 6in (0mm-152mm)	0in-2in (0mm-51mm)	FPW 1206	FPW 1212	FPW 1218	FPW 1224
6in-13in (152mm-330mm)	2in-4in (51mm-102mm)	FPW 1806	FPW 1812	FPW 1818	FPW 1824
13in-19in (330mm-483mm)	4in-6in (102mm-152mm)	FPW 2406	FPW 2412	FPW 2418	FPW 2424
19in-25in (483mm-635mm)	6in-8in (152mm-203mm)	FPW 3006	FPW 3012	FPW 3018	FPW 3024
25in-31in (635mm-787mm)	8in-10in (203mm-254mm)	FPW 3606	FPW 3612	FPW 3618	FPW 3624
31in-38in (787mm-965mm)	10in-12in (254mm-305mm)	FPW 4206	FPW 4212	FPW 4218	FPW 4224
38in-44in (965mm-1118mm)	12in-14in (305mm-356mm)	FPW 4806	FPW 4812	FPW 4818	FPW 4824
44in-53in (1118mm-1346mm)	14in-17in (356mm-432mm)	FPW 6006	FPW 6012	FPW 6018	FPW 6024

**NOTE:** Now that you have your measurements, you can use the graph above to help you find the appropriate FreezePro® Wrap part number. Diameter and circumference (length) measurements are listed in the table rows vertically (Y axis) and width measurements are listed in the column rows horizontally (X axis).



#### 4. GO AND ORDER ONLINE:

1. Go to [shop.unitherm.com](http://shop.unitherm.com)
2. Enter your part number in to the Search bar in the upper left-hand corner of the page
3. Click "**Search**" to get your FreezePro® Wrap Insulation Jacket